

NON-EXEMPT PRODUCTS

(WARNINGS REQUIRED)

1	Audio or video adapter cords for portable products
2	Audio or video cable for portable products
3	Audio/Video/Computer/telecommunications cables packaged individually for retail sales
4	Automotive cigarette lighter adapters
5	Blender (hand-held models)
6	Camera cords and accessories
7	Carving knife
8	CB radio handsets
9	Clip-on lights
10	Coffee grinder
11	Computer joystick
12	Computer mouse cords
13	Computer peripheral AC adapter cord and I/F cable for portable computers or portable peripheral devices
14	Computer peripheral PCMCIA card cord for portable computers
15	Computer peripheral wires & cables designed to plug into front of desktop computer (e.g., USB cords)
16	Computer peripheral wires & cables for portable computers and those
17	Computer speaker cords used with portable computers
18	Corded shaver
19	Corn popper
20	Curling iron
21	Data logger cable included with portable devices
22	Desktop computer power/patch/pin cords designed to plug into front of computer
23	External CD/DVD and tape drives for portable computers
24	Food processor/Chopper (hand-held models)
25	Griddle
26	Grill (countertop)
27	Hair clipper (corded)
28	Hair dryer
29	Hand held drink mixer
30	Hot pot/Kettle/Tea brewer (unless cord attached to separate base unit)
31	Ice crusher
32	Iron (unless cordless)
33	Juicer/Juice extractor (household or portable)
34	Laptop computer cords
35	Meat slicer (hand-held)
36	Mixer (hand-held models)
37	Microphone cable (except for cords powering base unit of cordless microphone system)
38	Mobile telephone accessories (except corded base units and permanent installations in automobiles)
39	MP3 player
40	Portable digital imaging equipment
41	Portable DVD player
42	Portable electric sewing machine
43	Portable fan/heater

NON-EXEMPT PRODUCTS

(WARNINGS REQUIRED)

44	Portable heater (unless designed for permanent installation)
45	Portable musical instruments and accessories, including power and adapter cords, (e.g. electronic keyboards, samplers, drums, guitars, amplifiers, monitors, patch cords, pick-ups)
46	Portable personal stereo
47	Portable power adapters (except for i) AC adapters for foreign outlets and other voltage converters or ii) auto power adapters and cord which are not designed to plug into cigarette lighter or similar in-dash power source)
48	Portable power inverters (for automotive use)
49	Portable television
50	Portable ZIP drives and accessories
51	Scanners for portable computers
52	Skillet
53	Slow cooker
54	Small portable hotplate power cords
55	Steam cooker
56	Stereo headphones (unless cordless)
57	Holiday String lights
58	Telephone handset cord
59	Telephone headset cord
60	USB, firewire cords
61	Vacuum
62	Waffle maker
63	Headphone/Headset cords (except for cords powering base unit of cordless system)
64	Extension cord
65	Massager (hand-held, not including back cushion massager or electric recliners/massage chairs)
66	Heating pad
67	Sandwich maker
69	Video game accessories
70	Electric thermos/carafe (without separate base unit)